

The Brainstorm Workbench

Assembly Instructions



cef

INNOVATE.CREATE.REPEAT.

Components

What's in the Box!

- 8 BRACE PLATES
- 4 LEGS
- 32 SCREWS 1/4-20 X 20MM SERRATED
- 4 THREADED CASTERS



Time to Assemble

Let's Get Started!



1

Lay the butcher block top upside down on a padded surface so as not to damage it. The frame comes attached to the top and should be snug, but not too tight.

2

Take legs as shown and turn until the inserts align with the holes in the frame. Use the 1/4-20 x 20mm serrated screws to bolt the leg to the frame. Repeat with each of the four corners until all legs are attached.

3

Once all the legs are attached and tight, go around the frame and tighten all the confirmat bolts that attach the frame to the table top.

Time to Assemble

Almost done...



4

Attach the brace plate to the leg and frame using the 1/4-20 x 20mm serrated bolts, two plates per leg, 8 in total.



5

Attach a threaded caster to each leg insert. Tighten with a 3/4" wrench until secure.



Completion

Yay!



Your table is now **complete** and ready to use! Above is an image of the Brainstorm Workbench fully assembled.